

1. I got the base of the desk organiser and sanded it down, so it was smooth and had no rough edges.
2. I cut out the pine pieces for the parts and labelled each face, so I knew which faces to connect. I used a band saw to cut out the pine making sure to cut slightly on the waste side of the line.
3. I glued together the corresponding faces using a traditional jointing method.
4. I then sanded each part to give a good aesthetic finish before I glued them onto the base.
5. I then sanded down the wood and then I used a plane to create the angle.
6. When I got the angle I wanted, I sanded it down to make it smooth and flat so there weren't any parts that would make it wobble if it sat on a flat surface.

